Quick Reference Guide

MiVoice 5320 IP Phone



Display

Ring/Message Indicator

Volume, Speaker and Mute Controls

Fixed Function Keys

Dial Pad

Navigation Page Keys

Programmable Feature Keys and Softkeys Transfer/Conference

Speaker

Handset



Speaker



Mute



Menu



Cancel



Redial







Message

Note: For more information about using other features and applications on your 5320 IP Phone, refer to 5320 IP Phone User Guide located at www.mitel.com, or contact your Administrator. SIP Users: Refer to the 5320/5330/5340 SIP User and Administrator Guide.

Make a Call

• Lift the handset OR

B Press (1)).

5 Dial the number OR

Press a Speed Call key OR

4 Press 123 1 OR

5 Dial the prefix for external calls (e.g. 9) and the number.

Answer a Call

② Lift the handset OR

3 Press (1), and begin speaking.

End a Call

4 Press X OR

Replace the handset.

Place a Call on Hold

◆ Press △

¬. The line key flashes.

Page 1 Replace the handset if necessary.

Retrieve a Call from Hold

I iff the handset OR

Press (1) .

Press the flashing line key.

Retrieve a Message

4 Press 🔍 . It flashes when a message is waiting. Follow the voice mail prompts to retrieve your message.

Transfer a Call

4 Press ~ 90 .

Dial the number. Wait for an answer.

 Hang up OR announce the transfer and then hang up.

Conference a Call

4 Press A SQ.

5 Dial the number. Wait for an answer.

4 Press 🗪 🗯 .

Program a Speed Call

4 Press Menu OR 🦣 .

Press Settings.

Press Programmable Keys.

Press the key you wish to program.

Press Speed Call.

Press Edit Info and enter the label for the Speed Call.

Press Save.

Press Edit Number and enter the phone number for the Speed Call.

Press Save, and then press Save again.

Press Close and then press Close again.

Adjust Volume Levels

Adjust ringer volume while the phone is ringing. Adjust handset or speaker volume while using the handset or speaker.

Press repeatedly to raise the volume OR repeatedly to lower the volume.

3 Press b to mute your microphone.

